


HORIZONTAL CONFIGURATIONS - CAN BE TOGGLES OR PUSH BUTTONS




IMPORTANT:

Please note that up to two push buttons fit per gang of a junction box but only one toggle can fit per gang.

Vertical configurations and Architrave configurations require specific junction boxes. Please consult with our sales team for information on suitable junction boxes to use.

All junction boxes must be recessed by at least 1/8" (3mm) below the finished wall surface. Refer to our Wallbox Assembly Diagrams.

VERTICAL CONFIGURATIONS - PUSH BUTTONS ONLY EXCEPT WHERE TOGGLES ARE DEPICTED



ARCHITRAVE CONFIGURATIONS - CAN BE TOGGLES OR PUSH BUTTONS

