



## HOME AUTOMATION

Forbes & Lomax dry contact push buttons and toggle switches are designed to be used as controls for panel-based home automation systems such as Lutron Homeworks, Crestron, Savant and Control 4. The switches connect to these systems using contact closure interfaces. Once connected, different functions can be assigned to the switches via programming in the system's software. Some typical examples of functions would be; selecting and dimming a lighting zone or scene, cycling through multiple scenes, switching the "whole house off", raising and lowering window shades. Cover plates can be custom engraved with text to denote the functions of each switch. See our [Integrating Forbes & Lomax with Home Automation Systems](#) technical sheet on our website. Some configurations of Forbes & Lomax dry contact switches only fit into specific junction boxes, so please consult with Forbes & Lomax to clarify what junction boxes to use. Also note that all junction boxes must be recessed below the finished wall surface by at least 1/8". See our [Junction Box Assembly Diagram](#) technical sheet. Technical sheets are available in the [Technical Section](#) on our website.

## FINISHES

The Invisible Lightswitch® Range *(pictured above)*  
 The Antique Bronze Range  
 The Aged Brass Range  
 The Unlacquered Brass Range  
 The Nickel Silver Range  
 The Stainless Steel Range  
 The Verdigris Range

## MODELS

Dry Contact: *For use on Class 2 Circuits only*  
 Momentary Push Button - *provides 1 Momentary contact closure*  
 Momentary 2-Position Toggle - *provides 1 Momentary contact closure*  
 Momentary 3-Position Toggle - *provides 2 Momentary contact closures*  
 Latching 3-Position Toggle - *provides 2 Maintained contact closures*

[ussales@forbesandlomax.com](mailto:ussales@forbesandlomax.com) | [www.forbesandlomax.com](http://www.forbesandlomax.com)